

SUPER HELP SRL

VIA VITTORIO VENETO, 11
21100 VARESE - ITALY
TEL +39-347-4650120
E-MAIL: info@super-help.com
WEB: www.super-help.com



TECHNICAL DATA SHEET SUPER HELP PEDAL DISPENSER COLUMN

Ref. : 325

1. GENERAL DESCRIPTION

Adjustable height Pedal dispenser column for Hands Sanitizing Gel. Entirely made in steel.
Protected with powder electrostatic coating.
It takes just a few seconds to be adjusted at desired height.
Does not require any tools to be assembled.

2. FEATURES

- Strong and steady structure, entirely in steel.
- Structure with pedal control.
- Hands free, no need to touch any part with your hands.
- Can be easily and fast adjusted at desired height.
- Bold and bright color, perfectly matching with Super Help Products Line.

3. APPLICATIONS

- Pedal control to sanitize your hands.
- Allows the use of various types of bottles with pump.

4. DIRECTIONS

- Open the carton box and take the Pedal Dispenser Column out.
- Carefully place the Pedal Dispenser Column on a steady floor.
- Caution: the weight of the Gel dispenser must not exceed kg. 1,0.
- Unlock the dispenser pump. Pump until the first gel comes out.
- Place the bottle on the dispenser shelf, adjust the wings so that the bottle is firmly locked.
(The bottles must have a minimum diameter of 65 mm and a maximum of 92 mm.)
- Carefully adjust the height of the dispenser shelf so that the pump slightly touch the plate.
- Place your right hand under the dispenser pump and lightly push the pedal for one second.
- Check several times a day that the Pedal Dispenser Column is on a stable floor.
- Check several times a day that the height of the dispenser holder shelf is correctly adjusted.
- Warning: the company shall not assume any responsibility due to the improper use of the Pedal Dispenser Column.
- For more information, click on the QR code here below printed.



6. PACKAGING

1 pc / carton

Carton size: 112 X 27 X 27 cm

Carton weight: kg. 4,500

Bar code Nr. 8028687003253



Technical drawing:



Date : 23-05-2020